### NORMAL CHECKLISTS C-172 PH-JBC

Note: Checks in blue are to be performed by memory!

DEFODE OT A DTING ENG	INIE
BEFORE STARTING ENG	
Gust lock & pitot cover	
Walk-around and visual inspection	nCOMPLETED
Aircraft documents	
Seats & seatbelts	
Doors & windows	
Parking brake Fuel selector	
All electrical switches	
Avionics master switch	
Circuit breakers	
Master switch	
Fuel quantity	
HOBBS & VUT	NOTED
110BBC & VOT	
STARTING ENGINE	
Mixture	RICH
Carburetor heat	
Prime	
Throttle	
Beacon light	ON
Propeller	CLEAR
Ignition switch	START
<b>AFTER STARTING ENGIN</b>	
Throttle	1000 RPM
Oil pressure	CHECK
Starter warning light	OFF
Ammeter	CHARGING (+)
Flaps	ÛP
Avionics master switch	ON
Radio equipment & transponder.	ON/SET/STBY
Flight instruments	SET & CHECKED
Parking brake	RELEASE
DURING TAXIING	
Brakes	CHECK
Instruments	
moti di nonto	
ENGINE RUNUP	
Throttle	1000 RPM
Parking brake	SET
Check behind	
Throttle	
Engine instruments	
Carburetor heat	
Carburetor heat	OFF
Magnetos (drop 125 rpm	
Ammeter	
Throttle idle	
Throttle	
Throttle friction	SET
BEFORE TAKE-OFF	
	CHECKED
Flight controls	SET EOD TAKE OFF
Flaps(Gr	
Transponder(Gi	
Landing light	
Pitot heat	
Crew/nay briefing	





AFTER TAKE-OFF (Above 200ft AAL)	
Flaps UP Landing light OFF	
BEFORE JOINING THE CIRCUIT  Altimeter SET QNH Primer CLOSED AND LOCKED Magnetos BOTH Landing light ON Fuel selector BOTH Mixture RICH Brakes CHECKED Seat belts FASTENED	
DOWNWIND (70 - 80 kts)  Carburetor heat	
BASE LEG (70 kts) Flaps	
FINAL (approach speed 60 - 70 kts) Flaps	
BALKED LANDING Throttle FULL Carburetor heat OFF Flaps 20° Speed MIN 56 kts	
AFTER LANDING           Flaps         UP           Carburetor heat         OFF           Landing light         OFF           Transponder         STBY           Pitot heat         OFF           AFTER PARKING         Throttle         1000 RPM           Parking brake         SET           Radio & transponder         OFF           Avionics master switch         OFF           All electrical switches (Except Beacon Light)         OFF           Mixture         IDLE CUT OFF           Beacon light         OFF           Ignition         OFF AND KEY REMOVED	
Master switch OFF HOBBS & VUT NOTED Emergency locator transmitter NOT TRIGGERED Gust lock & pitot cover INSTALL	





# ABNORMAL CHECKLISTS C-172 PH-JBC

Note: Checks in red are to be performed by memory!





#### **ENGINE FAILURES:**

ENGINE FAILURE DURING TAKEOFF RUN	
Throttle	IDLE
Brakes	APPLY
Flaps	RETRACT
Mixture	IDLE CUT OFF
Ignition switch	OFF
Maatar awitah	OFF

# ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF

Airspeed	(flaps down) 60 kts
Mixture	IDLE CÚT OFF
Fuel selector valve	OFF
Ignition switch	OFF
Flaps	AS REQUIRED
Master switch	OFF
Forced landing	EXECUTE
(As described in Emergency Landing Without Engine Power	
in the POH and ACHA Procedures)	

#### **ENGINE FAILURE DURING FLIGHT**

Airspeed	65 kts
Carburetor heat	ON/WARM
Fuel selector valve	BOTH
Mixture	RICH
Ignition switch	(START if propeller is stopped) BOTH
Primer	IN AND LÓCKED
(If engine fails to start)	
Forced landing	EXECUTE
(As described in Emergency Landing Without Engine Power	
in the POH and ACHA	Procedures)

#### **ENGINE FIRES:**

#### FIRES DURING START ON GROUND

IF ENGINE STARTS:	
Throttle	1700 RPM FOR A FEW MINUTES
Mixture	IDLE CUT OFF
IF ENGINE FAILS TO STAR	T:
	FULL OPEN
Mixture	IDLE CUT OFF
	CONTINUE
Engine	SECURE
Master switch	OFF
Ignition switch	OFF
Fuel selector valve	OFF

Cranking ...... CONTINUE

#### **ENGINE FIRE IN FLIGHT**

in the POH and ACHA Procedures)

Mixture	IDLE CUT-OFF	
Fuel selector valve	OFF	
Master switch	OFF	
Cabin heat and air (except o	verhead vents) OFF	
Airspeed	100 kts	
(if fire is not extinguished, increase glide speed to find an		
airspeed which will provide an incombustible mixture)		
Forced landing	EXECUTE	
(As described in Emergency Landing Without Engine Power		

### **ELECTRICAL FIRE IN FLIGHT**

Master switch	
Avionics power switch	OFF
All other switches(except ignition)	
Vents/cabin air/heat	
if fire appears out and electrical power is necess	
continuance for flight	•
Master switch	ON
Circuit breakers	
for faulty circuit, do not reset	0112011
Radio switches	OFF
Avionics power switch	ON
Radio/electrical switches	
one at a time, with delay after each until short cir	
is localized	ouit
Vents/cabin air/heat	OPEN
when it is ascertained that fire is completely extin	
when it is ascertained that the is completely extin	iguisileu
CADIN FIDE	
CABIN FIRE	
Master switch	
Vents/cabin air/heat	CLOSED

Land...... AS SOON AS POSSIBLE

### ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS:

### INSUFFICIENT RATE OF CHARGE (Ammeter shows discharge during flight)

(,ge and	····ອ ···ອ·· <i>·</i> /
Alternator	OFF
Non-essential radio/electrical equipment	OFF
LandAS S	SOON AS PRACTICAL

# **EXCESSIVE RATE OF CHARGE**Over voltage light is illuminated

Avionics power switch	
Master switch	(both sides) OFF
Master switch	ON
Over voltage light	CHECK OFF
Avionics power switch	ON
IF OVER VOLTAGE LIGHT IL	
Land	AS SOON AS POSSIBLE

#### NOTE:

This checklist is a Recommended Operator Checklist and for reference only. It is not a substitute for and does not supersede the current approved Airplane Flight Manual. For a comprehensive listing see the Airplane Flight Manual.